Pre-Contractual Data Information: Connected Product (EU Data Act)

Product	8808A 240V, 8808A/RS 240V, 8808A/SU 240V, 8808A/TL 240V
Firmware / HW	Various
Connectivity / Interfaces	RS-232 and USB with supplied RS-232 to USB adapter
Contact	privacypolicy@fluke.com

1) Product data

- **Physical measurements:** DC voltage, DC current, resistance, continuity/diode, AC voltage, AC current, frequency/period
- **Device identifiers:** The response to *IDN gives “FLUKE, 8808A, nnnnnnn, n.n Dn.n”, where nnnnnnn is the serial number, n.n the main firmware version and Dn.n the display firmware version
- **Status / telemetry:** Status byte and event status register bits, described in the programmer’s manual (see section 4 below)
- **Events & diagnostics:** Measurement outside limit range warning
- **Configuration values:** Six configurable preset configurations

Estimated volume (typical): Determined by user application and setting.

Collection Frequency: Internal trigger: selectable slow (2.5) / medium (20) / fast (100). Frequency and continuity are fixed. External trigger: trigger signal input.

For general operational guidance, please refer to the product’s user manual.

2) Data formats

- Measurements from the main and auxiliary displays are returned to a terminal emulator as 7-bit ASCII strings in floating-point format in response to query commands. This can be the measurements currently displayed, or the measurement after the next trigger is complete.
- The instrument can be configured to send measurements as they occur to an RS-232 printer.

3) Storage & retention

- **On-device storage:** Main and auxiliary display values. No other measurement store. There are registers associated with the serial interface and instrument configuration, such as baud rate, measurement limits, and status (for example, outside preset limits).
- **Cloud / servers:** No cloud storage or servers. No data is collected by Fluke during operation.
- **Retention:** Measurements are updated on trigger and cleared by power cycle.
- **Deletion/anonymization:** Measurements are cleared by power cycle or updated by trigger.

4) User access, export & erase

- **Where:** Download an open source terminal emulator such as Tera Term — **https://sourceforge.net/projects/tera-term/**

- **How:** Connect with a serial cable, or USB to the adapter. Send ASCII commands from the user manual — **https://www.fluke.com/en-gb/product/precision-measurement/bench-instruments/fluke-8808a** — to retrieve measurements from the displays.
- **Export formats:** 7-bit ASCII strings; measurements in floating-point format.
- **Limits/rate-limits:** For continuous mode see the maximum read rates above, or as determined by the external trigger input.
- **Request erasure:** None, as measurements are the front-panel displayed values. Retrigger to change.

5) Data Sharing with Third Parties

To the extent Fluke has access to the relevant data, you may authorize a third party to access such data by contacting Fluke using the details set out above, specifying the recipient and purpose of the data sharing. You may view and revoke authorized data transfers at any time via the same contact details.

Where data is stored locally on your device or within your own environment and is not accessible to Fluke, you are responsible for granting third-party access directly.

6) Terms of service, contract term & termination

As provided in the quote, order form, or agreement between you and Fluke. If you purchased the product through a distributor or reseller, the terms of service, contract term and termination are as agreed between you and that seller.

7) How Data Holder uses the data

If Fluke has access to any data generated through your use of a Fluke connected product or related service, this will be used in accordance with the applicable agreement between you and Fluke, through which you purchase Fluke's products or services. The relevant Fluke entity details will be specified in the quote or order form as applicable.

Fluke may engage third parties to act as service providers and perform certain tasks on its behalf, such as processing or storing data generated in connection with your use of a Fluke connected product or related service. For more information, please visit **https://www.fluke.com/en-us/fluke/privacy-policy**

8) Trade secrets

No trade secrets are contained in the data.

9) Right to lodge a complaint

If you have a complaint relating to your Fluke connected product or related service, or the Data Act in general, you can contact Fluke using the details set out above. You also have the right to lodge a complaint with the relevant competent authority designated under Article 37 of the EU Data Act, in the Member State of your habitual residence, place of work or establishment.

Notice version: 1.0 **Last updated:** 2026-08-25